

LEVEL-ID™

OPERATIONAL EXCELLENCE & CRITICAL/QUALITY ALERT



Class 1, Division 1 Rated (EX) pictured

REAL-TIME NON-INTRUSIVE INDEPENDENT LEVEL OF AN ELEVATED TANK

- API 2350 Compliant Indepedent Alarm
- Capital Purchase or Lease Option Available
- Real Time Fluid Level Detection
- WiFi, Cellular, or Modbus Communications Options
- C1D1 Certified or General Purpose
- Small Footprint (wraps outside of pipe)

Non-intrusive Installation

Low Power (24 VDC Hardwired)

ORDERING PROCESS: (EXAMPLE: EC1000A:B1:C1:MA:EX:1:W1:Y:HW)

	<u> </u>									
		BASE MODEL	HOUSING	MOUNTING STYLE	NTING MOUNTING	CLASS	POWER	MODBUS	EDGE	ES COMM
	(example)	LD1000A	B1 :	C1 :	MA :	EX	: 1	: W1 :	Υ	: HW
YOUR ORDER:		LD1000A								
		BASE MODEL	HOUSING	PIPE SIZE	MOUNTING	CLASS	POWER	MODBUS	EDGE	ES COMM







perceptivesensors.com

MODEL NUMBER

OPERATIONAL EXCELLENCE & CRITICAL/QUALITY ALERT PST PRODUCT:

BASE MODEL #	DESCRIPTION
LD1000A	Level Alarm with Digital Output
HOUSING STYLE	
mm B1	Integral Sensor and Electronics
B2	Electronics remote mounts from sensor via 6' cable for mounting electronics remote
MOUNTING SURFACE	
<u>C1</u>	Adaptable for curved or flat tanks
MOUNTING	
EP	Epoxy Mount System (Ashesive Included)
PC	Pipe Clamp
MA	Magnet (hurricane rated)
SM	Magnet (hurricane rated, secured for anti theft)
ENCLOSURE / CLASSIFICATION	
G P	NEMA 4X / General Purpose
EX	Class 1 Groups C, D Class 2 Groups E, F, G (rated)
POWER	
1	Hardwired DC Power 24VDC (Class II Power Supply provided by customer)
MODBUS COMMUNICATION	(COMMUNICATION FROM PIPE MOUNTED DEVICE TO EDGE SERVER)
H1	Hardwired Modbus RTU RS485
W1	Wireless Modbus RTU RS485 (900 MHz Following ISA/SP100 Standards)
EDGE SERVER	(NON-PST EDGE SERVER VOIDS WARRANTY)
Υ	Yes, I need an Edge Server
N	No, I already have a PST Edge Server I will use at my facility
EDGE SERVER COMMUNICATIO	NS (COMMUNICATION FROM EDGE SERVER TO DEVICE CONSUMING THE DATA/CLOUD BACKUP)
WF	WiFi - 2.4 GHz (802.11 b/g/n)(Ability to connect to customer WiFi network)
C1	Cellular (AT&T) (Customer Data Plan Required) (Used for cloud backup if desired)
	Handwined Ethannat Only
HW NA	Hardwired - Ethernet Only I already have a PST Edge Server at my facility



HOW DO YOU WANT YOUR SENSOR TO COMMUNICATE WITH THE PST EDGE

HARDWIRED MODBUS RTU RS485 (SELECT H1)

WIRELESS MODBUS RTU RS485 (SELECT W1)

EDGE SERVER COMMUNICATION



ETHERNET/INTERFACE INTO LOCAL NETWORK (SELECT WF)

CELLULAR (AT&T) (SELECT C1)

HARDWIRED MODBUS RTU RS485 (SELECT HW)



CLOUD OR CUSTOMER CONTROL SYSTEM



PST SENSOR